

Standard Series
STEREO SPEAKERS
USER'S MANUAL



MODERN SOUND FOR YOUR CLASSIC

www.retromanufacturing.com

TABLE OF CONTENTS

WELCOME.....	2
PRECAUTIONS.....	3
INSTALLATION INSTRUCTIONS.....	4
SPECIFICATIONS.....	6
LIMITED WARRANTY.....	7
INSTALLATION NOTES.....	8

The information enclosed in this manual is to be used as a guide to assist you with installation and operation of your speakers. This guide does not cover every installation possibility, vehicle, or every aspect of the installation process.

Retro Manufacturing, LLC, or its subsidiaries, assume no responsibility for any installation. This manual may be updated from time to time.

Visit our website for the latest version:
www.retromanufacturing.com.

Thank you for purchasing RetroSound® Standard-Series Stereo Speakers.

RetroSound® Stereo Speakers

- Standard magnet structure for thin design and high power handling
- Treated foam surround for smooth, natural sound
- Mylar® tweeters for crisp, clear highs
- Poly cone for accurate mid-bass
- Dip-cut back plate for extended pole piece excursion

RetroSound® standard-series stereo speakers offer outstanding sound quality. A standard magnet structure ensures high power handling capability and excellent bass response. They use treated foam surrounds for a smooth, natural mid-bass response and exceptional durability in the automotive environment. Mylar® tweeters produce crisp, clear, natural high frequencies. The back plate is dip-cut, which enables extended pole piece excursion for high output.

PRECAUTIONS

Precautions

It is best to consult a professional installation specialist to help with your installation.

Prior to installation, always follow these rules:

- Carefully read and understand the instructions before attempting installation.
- Always disconnect the negative (-) battery terminal. Failure to do so may result in damage to the unit, fire, injury or death.
- Use high quality connectors to prevent fire or damage to the unit.
- Check the installation area before drilling. Make sure you won't drill into the gas tank, fuel lines, brake lines, hydraulic lines, vacuum lines or electrical wiring.
- Never run wires underneath the vehicle.
- Avoid running wires over sharp edges. Use rubber grommets to protect any wires routed through metal.

INSTALLATION INSTRUCTIONS

The following tools may be needed for installation of your RetroSound® speakers

- #2 Phillips screwdriver
- Battery post wrench
- Hand held drill with assorted bits
- Wire strippers
- Wire crimpers
- Wire cutters

Included in your box are two speakers, speaker wires, speaker grilles (some models) and mounting screws.

Before installation, disconnect the negative (-) battery terminal to prevent damage to your system.

Mounting

1. Run speaker wires before installing your speakers. Avoid sharp edges that could fray or cut the wiring. Use rubber grommets to protect any wires that need to be routed through metal. Use high quality connectors to minimize signal loss. Never run wires outside the vehicle.
2. Determine the area where the speakers are to be mounted. Ensure that the area is large enough to accommodate the entire speaker diameter and that there is enough mounting depth for the speaker magnet. If you are mounting your speakers in the doors, check all door functions (windows, door locks, etc) through their entire range of motion to ensure the speaker will not obstruct them.

INSTALLATION INSTRUCTIONS

3. If you are cutting speaker holes, refer to the specification chart to determine the nominal mounting diameter.
4. Using the speaker grille as a template, mark the locations for the speaker mounting screws. Drill the holes with a 1/8-inch drill bit.
5. Feed the speaker wires through the opening and connect to the speaker terminals. Take care to connect the negative wire to the negative (-) speaker terminal, and positive to the positive (+) speaker terminal.
6. Fit the speaker into the cutout. Fit the grille over the speaker. Mount them using the enclosed screws. Tighten until the speaker is snug and in place to prevent rattling. Do not overtighten screws.

SPECIFICATIONS

MODEL	S-42	S-52	S-412	S-692
Nominal Diameter (inch)	4	5.25	4x10	6x9
Description	2-Way	2-Way	2-Way	2-Way
Nominal Impedance	4ohm	4ohm	4ohm	4ohm
Frequency Response	65H-21kHz	50Hz-21kHz	43Hz-21kHz	40Hz-21kHz
Sensitivity (SPL@1w/1m)	88dB	87dB	87dB	90dB
Power Handling (watts RMS/peak)	25/50	25/50	25/50	50/100
Speaker Grille	NO	NO	NO	YES
Mounting Depth (inch)	1.4	1.7	2.3	3.1
Mounting Depth (mm)	36	44	59	79

*The above specifications are subject to change without notice.

LIMITED WARRANTY

If your unit does not work properly because of defects in materials or workmanship, Retro Manufacturing, LLC (collectively referred to as "the warranter") will, for the length of the period indicated in the chart below, which starts with the date of original purchase ("warranty period"), at its option either (a) repair your unit with new or refurbished parts, or (b) replace it with a new or refurbished unit. The decision to repair or replace will be made by the warranter.

CATEGORIES	PARTS	LABOR
Speakers	One (1) Year	One (1) Year

During the "Labor" warranty period, there will be no charge for labor. During the "Parts" warranty period, there will be no charge for parts. You must mail in your unit prepaid during the warranty period. This warranty only applies to products purchased and serviced in the United States or Puerto Rico. This warranty is extended only to the original purchaser of a new product which was not sold "as is." A purchase receipt or other proof of the original purchase date is required for warranty service.

To handle a warranty issue, contact us at tech@retromanufacturing.com or 888.325.1555 for a Return Authorization number. All returns and warranty issues must be accompanied by a Return Authorization (RA) number. Any product received without a RA number will be refused.

LIMITED WARRANTY-LIMITS AND EXCLUSIONS

This warranty ONLY COVERS failures due to defects in materials or workmanship. This warranty ALSO DOES NOT COVER damages which occurred during shipment, failures which are caused by products not supplied by the warranter, failures which result from accident, misuse, abuse, neglect, pest infestation, mishandling, misapplication, alteration, faulty installation, set-up adjustment, improper voltage, lightning strikes, maladjustment of consumer control, improper maintenance, modification, commercial use or rental use of the product, or service by anyone other than Retro Manufacturing, LLC, or damage that is attributable to acts of God.

THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY". THE WARRANTER IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS SYSTEM, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. (As examples, this excludes damages for lost time, cost of having someone remove or re-install an installed unit if applicable, travel to and from the servicer. The items listed are not exclusive, but are for illustration only.) ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. If a problem with this unit develops during or after the warranty period, you may contact your dealer or Retro Manufacturing, LLC. Warranty only valid in U.S.A. and Canada only.

